Operation Instructions


M-602 Wireless Touch Switch



Safety Instruction

Thanks for your purchasing, please refer to the following before using.

2 Product Overview



3 Matching Methods

- This product is self-learning code. Before using it, the transmitter code must learned into the controller. The controller can learn up to 20 transmitters.
- Learning method: Press the receiver's learning button, the blue indicator is on, enter the learning state. At this time, touch the transmitter's induction area, the blue indicator of the receiver will flash three times, then learning successfully. After 5 seconds, it will automatically return to the standby state.
- Delete method: Press and hold the learning button for 5 seconds, the blue light flashes quickly, all codes will be deleted. (Every code can't be deleted individually)

4 Output status selection

- ① M If in the M position, it is inching output. Each time the transmitter touches, it will output a door opening signal of about 1.5S. ↓ ↓ Most choose this mode.
- M If in the L position, it is holding output, the output signal is kept.
 Each time the transmitter touches, the output state will change once.
- 3 M Normally open function in M state: If in the M-point state, the transmitter is continuously touched for 10 seconds to see that the indicator light flashes and the receiver enters the normally open state. When the transmitter is touched again, the normally open state is released.

5 Technical Parameter

Wireless receiver

Power supply : Static current: Action current: Main contact capacity: Contact suction holding time: Product size: DC12~30V 34mA(DC12V) 62mA(DC12V) 1A 24VDC 1.5 Seconds 110(L)x30(W)x15(H)mm

Transmitter Power supply: Standby current: Emission current: Life of battery: Receiver sensitivity: Emission distance: Product size:

3V(2pcs 3V button battery) ≤5µA 10.5mA 200 times/day, about 16 months -95dbm Over 30 meters in no obstacles area 135(L)x36(W)x10(H)mm



Remark: Since the system has learned the current touch environment when the battery is installed, when fixing it to the wall, it may appear to be in the sensing status. Don't touch the panel at this time, after 16 seconds the system will re-learn the touch environment.